

Sidewalks & Driveways

- Use expansion joints to run cable across when sleeves are not feasible
 - Cut the expansion joint with a masonry blade to widen the joint for the cable.
 - Use the masonry dust with a little cement powder to sweep into the masonry joint to hide cable.
- Drill hole in concrete at an angle to run cable back under ground to protect against cuts

